


Analysis of vibrations in structures after Achmus
(Bulletin 61, Hannover University)

GGU-VIBRATION

VERSION 2



Last revision: February 2018
Copyright: Prof. Dr. Johann Buß
Technical implementation and sales: Civilserve GmbH, Steinfeld

Contents:

- 1 Preface 4**
- 2 Licence protection and installation 4**
- 3 Language selection 4**
- 4 Starting the program 5**
- 5 Description of menu items 6**
 - 5.1 File menu 6
 - 5.1.1 "New" menu item 6
 - 5.1.2 "Load" menu item 6
 - 5.1.3 "Save" menu item 6
 - 5.1.4 "Save as" menu item 6
 - 5.1.5 "Printer preferences" menu item 6
 - 5.1.6 "Print and export" menu item 7
 - 5.1.7 "Batch print" menu item 9
 - 5.1.8 "Exit" menu item 9
 - 5.1.9 "1, 2, 3, 4" menu items 9
 - 5.2 Edit menu 10
 - 5.2.1 "Project identification" menu item 10
 - 5.2.2 "Choose equipment" menu item 10
 - 5.2.3 "System parameters" menu item 11
 - 5.2.3.1 General note 11
 - 5.2.3.2 Vibrating pile driver 11
 - 5.2.3.3 Driving ram (diesel hammer) 13
 - 5.2.3.4 Driving ram (drop hammer) 14
 - 5.2.3.5 Vibrating plate 15
 - 5.2.3.6 Vibratory roller 16
 - 5.2.3.7 Deep vibrator 17
 - 5.2.3.8 Selecting and managing equipment 17
 - 5.3 System menu 19
 - 5.3.1 "Analyse" menu item 19
 - 5.4 Output preferences menu 20
 - 5.4.1 "General legend" menu item 20
 - 5.4.2 "Diagram" menu item 21
 - 5.4.3 "Page size and margins" menu item 22
 - 5.4.4 "Move objects" menu item 22
 - 5.5 Graphics preferences menu 23
 - 5.5.1 "Refresh and zoom" menu item 23
 - 5.5.2 "Zoom info" menu item 23
 - 5.5.3 "Legend font selection" menu item 23
 - 5.5.4 "With borders" menu item 23
 - 5.5.5 "Pen colour and width" menu item 24
 - 5.5.6 "Mini-CAD toolbar" menu item 24
 - 5.5.7 "Toolbar preferences" menu item 24
 - 5.5.8 "Load graphics preferences" menu item 25
 - 5.5.9 "Save graphics preferences" menu item 25

5.6	Info menu	26
5.6.1	"Copyright" menu item	26
5.6.2	"Help" menu item	26
5.6.3	"GGU on the web" menu item	26
5.6.4	"GGU support" menu item.....	26
5.6.5	"What's new?" menu item.....	26
5.6.6	"Language preferences" menu item	26
6	Tips and tricks.....	27
6.1	Keyboard and mouse.....	27
6.2	Function keys	27
6.3	"Copy/print area" icon.....	28
7	Index.....	29

1 Preface

The **GGU-VIBRATION** program system facilitates the analysis of vibrations in structures after Achmus, Kaiser and tom Wörden (*'Bauwerkerschütterungen durch Tiefbauarbeiten'* in Bulletin 61, IGBE, Hannover University). Example 1 (vibration roller) and Example 2 (driving ram (diesel hammer)) from Prof. Achmus' article are provided as files.

The theoretical principles are included in Bulletin 61 (IGBE, Hannover University). They will therefore only be repeated for this manual as far as necessary to describe the input.

Data input is in accordance with conventional WINDOWS operations and can therefore be learned almost entirely without the use of a manual. Graphic output supports the true-type fonts supplied with WINDOWS, so that excellent layout is guaranteed. Colour output and any graphics (e.g. files in formats BMP, JPG, PSP, TIF, etc.) are supported. DXF files can also be imported by means of the integrated Mini-CAD module (see the "**Mini-CAD**" manual).

The program has been thoroughly tested. No faults have been found. Nevertheless, liability for completeness and correctness of the program and the manual, and for any damage resulting from incompleteness or incorrectness, cannot be accepted.

2 Licence protection and installation

In order to guarantee a high degree of quality, a hardware-based copy protection system is used for the **GGU-VIBRATION** program.

The GGU software protected by the *CodeMeter* copy protection system is only available in conjunction with the *CodeMeter stick* copy protection component (hardware for connection to the PC, "*CM stick*"). Because of the way the system is configured, the protected software can only be operated with the corresponding CM stick. This creates a fixed link between the software licence and the CM stick copy protection hardware; the licence as such is thus represented by the CM stick. The correct Runtime Kit for the CodeMeter stick must be installed on your PC.

Upon start-up and during running, the **GGU-VIBRATION** program checks that a CM stick is connected. If it has been removed, the program can no longer be executed.

For installation of GGU software and the CodeMeter software please refer to the information in the *Installation notes for GGU Software International*, which are supplied with the program.

3 Language selection

GGU-VIBRATION is a bilingual program. The program always starts with the language setting applicable when it was last ended.

The language preferences can be changed at any time in the "**Info**" menu, using the menu item "**Spracheinstellung**" (for German) or "**Language preferences**" (for English).

4 Starting the program

After starting the program, you will see two menus at the top of the window:

- File
- Info

After clicking on the "**File**" menu, a previously calculated system can be loaded by means of the "**Load**" menu item, or a new one created using "**New**".

After clicking "**New**" the program automatically jumps to the option box, which can also be opened by going to the "**Edit/Choose equipment**" menu item (see Section 5.2.2). Once the equipment has been selected a dialog box opens for system parameter input (also see the menu item "**Edit/System parameters**", Section 5.2.3). After closing the dialog box the start-up screen containing the general legend for the system data already entered is displayed. Six menus are visible in the menu bar:

- File
- Edit
- System
- Output preferences
- Graphics preferences
- Info

After clicking one of these menus, the so-called menu items roll down, allowing access to all program functions.

The program works on the principle of *What you see is what you get*. This means that the screen presentation represents, overall, what you will see on your printer. In the last consequence, this would mean that the screen presentation would have to be refreshed after every alteration you make. For reasons of efficiency and as this can take several seconds for complex screen contents, the **GGU-VIBRATION** screen is not refreshed after every alteration.

If you would like to refresh the screen contents, press either [F2] or [Esc]. The [Esc] key additionally sets the screen visualisation back to your current zoom, which has the default value 1.0, corresponding to an A4 format sheet.

5 Description of menu items

5.1 File menu

5.1.1 "New" menu item

A new analysis using a different vibration generator can be started. After going to this menu item the option box opens to allow selection of the equipment (see menu item "**Edit/Choose equipment**", Section 5.2.2). Once a different piece of equipment has been selected the dialog box for the "**Edit/System parameters**" menu item opens (see Section 5.2.3) and the system parameters can be entered.

5.1.2 "Load" menu item

You can load a file with system data, which was created and saved at a previous session, and then edit the system.

5.1.3 "Save" menu item

You can save data entered or edited during program use to a file, in order to have them available at a later date, or to archive them. The data is saved without prompting with the name of the current file.

5.1.4 "Save as" menu item

You can save data entered during program use to an existing file or to a new file, i.e. using a new file name. For reasons of clarity, it makes sense to use ".**ggu_vib**" as file suffix, as this is the suffix used in the file requester box for the menu item "**File/Load**". If you choose not to enter an extension when saving, ".**ggu_vib**" will be used automatically.


5.1.5 "Printer preferences" menu item

You can edit printer preferences (e.g. swap between portrait and landscape) or change the printer in accordance with WINDOWS conventions.

5.1.6 "Print and export" menu item

You can select your output format in a dialog box. You have the following possibilities:


- **"Printer"**
allows graphic output of the current screen contents. to the WINDOWS standard printer or to any other printer selected using the menu item **"File/Printer preferences"**. But you may also select a different printer in the following dialog box by pressing the **"Printer prefs./change printer"** button.



In the upper part of the dialog box, the maximum dimensions which the printer can accept are given. Below this, the dimensions of the image to be printed are given. If the image is larger than the output format of the printer, the image will be printed to several pages (in the above example, 4). In order to facilitate better re-connection of the images, the possibility of entering an overlap for each page, in x and y direction, is given. Alternatively, you also have the possibility of selecting a smaller zoom factor, ensuring output to one page ("**Fit to page**" button). Following this, you can enlarge to the original format on a copying machine, to ensure true scaling. Furthermore, you may enter the number of copies to be printed.

- **"DXF file"**
allows output of the graphics to a XF file. DXF is a common file format for transferring graphics between a variety of applications.
- **"GGU-CAD file"**
allows output of the graphics to a file, in order to enable further processing with the **GGU-CAD** program. Compared to output as a DXF file this has the advantage that no loss of colour quality occurs during export.

- **"Clipboard"**
The graphics are copied to the WINDOWS clipboard. From there, they can be imported into other WINDOWS programs for further processing, e.g. into a word processor. In order to import into any other WINDOWS program you must generally use the *"Edit/Paste"* function of the respective application.
- **"Metafile"**
allows output of the graphics to a file in order to be further processed with third party software. Output is in the standardised EMF format (Enhanced Metafile format). Use of the Metafile format guarantees the best possible quality when transferring graphics.


If you select the **"Copy/print area"** tool  from the toolbar, you can copy parts of the graphics to the clipboard or save them to an EMF file. Alternatively you can send the marked area directly to your printer (see **"Tips and tricks"**, Section 6.3).

Using the **"Mini-CAD"** program module you can also import EMF files generated using other GGU applications into your graphics.

- **"Mini-CAD"**
allows export of the graphics to a file in order to enable importing to different GGU applications with the **Mini-CAD** module.
- **"GGUMiniCAD"**
allows export of the graphics to a file in order to enable processing in the **GGUMiniCAD** program.
- **"Cancel"**
Printing is cancelled.

5.1.7 "Batch print" menu item

If you would like to print several appendices at once, select this menu item. You will see the following dialog box:



Create a list of files for printing using "**Add**" and selecting the desired files. The number of files is displayed in the dialog box header. Using "**Delete**" you can mark and delete selected individual files from the list. After selecting the "**Delete all**" button, you can compile a new list. Selection of the desired printer and printer preferences is achieved by pressing the "**Printer**" button.

You then start printing by using the "**Print**" button. In the dialog box which then appears you can select further preferences for printer output such as, e.g., the number of copies. These preferences will be applied to all files in the list.

5.1.8 "Exit" menu item

After a confirmation prompt, you can quit the program.

5.1.9 "1, 2, 3, 4" menu items

The "**1, 2, 3, 4**" menu items show the last four files worked on. By selecting one of these menu items the listed file will be loaded. If you have saved files in any other folder than the program folder, you can save yourself the occasionally onerous *rummaging* through various sub-folders.

5.2 Edit menu


5.2.1 "Project identification" menu item

A description can be entered; it will then be included in the *General legend* (see Section 5.4.1).

The equipment adopted is entered automatically and does not need to be entered via this menu item.

5.2.2 "Choose equipment" menu item

This menu item opens a dialog box allowing the user to choose between five different pieces of vibration generating equipment.



This dialog box opens automatically when a new analysis needs to be started, i.e. when starting the program or clicking the menu item "**File/New**".

5.2.3 "System parameters" menu item

5.2.3.1 General note

This is the program's central menu item, allowing input of the fundamental system parameters for the analysis. This menu item's dialog box differs slightly in appearance depending on the vibration generator selected.

All data entered using this menu item are displayed in the *General legend* on the output sheet (see Section 5.4.1).

5.2.3.2 Vibrating pile driver

For a vibrating pile driver the following "Edit/Systemparameters" dialog box opens:

The dialog box contains the following fields and values:

Section	Field	Value
Base data	Type of building	Residential
	Analyse for:	Unfavourable values
	Distance to building r [m]:	10.0
Equipment	Equipment name:	
	Vibrating pile driver power [kW]:	70.0
	Vibrating pile driver frequency [1/s]:	50.0
Transmission coefficients	Horizontal transmission coeff. (component) [-]:	2.00
	Vertical transmission coeff. (component) [-]:	1.50

One of three building types can be selected for investigation of the vibration impact in the "**Type of building**" box:

- Commercial and industrial buildings
- Residential buildings
- Particularly sensitive buildings.

Based on the investigated building type the program determines the allowable vibration velocities according to Table 7.1 in Bulletin 61 (IGBE, Hannover University), which are then compared to the existing vibration velocities once analysis is complete. The program issues a warning message if the allowable values are exceeded.

"**Analyse for**" specifies whether the analysis is carried for "**Unfavourable values**" or for "**Probable values**". In this context "**Unfavourable values**" means that damage was identified for 2.25% of the measured data evaluated by ACHMUS et al (2.25% exceeding probability). "**Probable values**" have an exceeding probability of 50%.

The resulting ground vibration acceleration $a_{\text{Ground,R}}$ is calculated using Equation 7.2 in Bulletin 61:

$$a_{\text{Ground,R}} = 2 \cdot \pi \cdot f \cdot v_{\text{Ground,R}}$$

The variable f represents the working frequency of the equipment.

The building settlement hazard can be assessed using the resulting ground vibration acceleration $a_{\text{Ground,R}}$. The allowable value, including for soils susceptible to collapse, is:

$$a_{\text{Ground,R}} \leq 1/3 \cdot g = 3,300 \text{ mm/s}^2 = 3.3 \text{ m/s}^2$$

The program issues a warning message if the allowable values are exceeded.

The distance of the selected equipment to the building is given in "**Distance to building**". Of course, the greater the distance, the lower the impact on the building.

The power [kW] and frequency [1/s] or [Hz] of vibrating pile drivers must be given. The maximum component of the footing vibration velocity $v_{F,i,\text{max}}$ according to Table 9.3 in Bulletin 61 is computed using these values. In the central area of the dialog box the equipment name and the corresponding data can be entered manually. Alternatively, the required equipment can be selected from a list of common commercial appliances and be adopted by the program by pressing the "**Equipment data**" button at the bottom of the "**Vibrating pile driver**" dialog box (see Section 5.2.3.8).

The transmission coefficients only need now be entered in the lower group box of the dialog box "**Vibrating pile driver**". The maximum component of the footing vibration velocity $v_{F,i,\text{max}}$ computed above is multiplied by these factors. The resulting values can be compared to the allowable values given in Table 7.1 in Bulletin 61 in order to assess the impact on the selected building type. Two message boxes provide information on the required input.

5.2.3.3 Driving ram (diesel hammer)

For a driving ram (diesel hammer) the following "Edit/Systemparameters" dialog box opens:

The dialog box contains the following fields and values:

- Base data:**
 - Type of building: Residential
 - Analyse for: Unfavourable values
 - Soil: Stones
 - Ground is: very firm or dense
 - Distance to building r (m): 10.0
- Equipment:**
 - Equipment name: (empty)
 - Energy per blow [kN·m]: 156.0
 - Vibration frequency [Hz]: 10.0
- Transmission coefficients:**
 - Horizontal transmission coeff. (component) [-]: 2.00 (Info)
 - Vertical transmission coeff. (component) [-]: 1.50 (Info)

Buttons: OK, Equipment data, Cancel

The input corresponds to the input for vibrating pile drivers (see Section 5.2.3.2).

The predominant soil type is entered for "Soil". Three soil types are differentiated:

- Cohesive soils
- Gravels, sands
- Stones.

This input is important for analysis of the resulting ground vibration acceleration $a_{\text{Ground,R}}$ according to Equation 9.1 and Table 9.2 in Bulletin 61. The building settlement hazard can be assessed using the resulting ground vibration acceleration $a_{\text{Ground,R}}$. The allowable value, including for soils susceptible to collapse, is:

$$a_{\text{Ground,R}} \leq 1/3 \cdot g = 3,300 \text{ mm/s}^2 = 3.3 \text{ m/s}^2$$

The program issues a warning message if the allowable values are exceeded.

For computation of the resulting ground vibration acceleration $a_{\text{Ground,R}}$ "soft or loose ground" and "very firm or dense ground" are differentiated according to Table 9.2. This setting is made in "Ground is".

In the "**Equipment**" group box in place of power and frequency, however, the energy per stroke [kN·m] and vibration frequency [Hz] or [1/s] are entered. Vibration frequency input is only required for determining the allowable values according to Table 7.1 in Bulletin 61. Resonant frequencies are not anticipated for impact driving.

Here, too, the equipment data can be selected and adopted from a list of common commercial appliances using the button of the same name. Equipment selection and editing of the equipment list are described separately in Section 5.2.3.8.

5.2.3.4 **Driving ram (drop hammer)**

For a driving ram (drop hammer) vibrating plate the following "**Edit/Systemparameters**" dialog box opens:

Base data	
Type of building	Residential
Analyse for:	Unfavourable values
Soil:	Stones
Ground is	very firm or dense
Distance to building r [m]:	10.0

Equipment	
Equipment name:	
Energy per blow [kN·m]:	156.0
Vibration frequency [Hz]:	10.0

Transmission coefficients	
Horizontal transmission coeff. (component) [-]:	2.00
Vertical transmission coeff. (component) [-]:	1.50

The input corresponds to the input for driving ram with diesel hammer (see Section 5.2.3.3).

Here, too, the equipment data can be selected and adopted from a list of common commercial appliances using the button of the same name. Equipment selection and editing of the equipment list are described separately in Section 5.2.3.8.

5.2.3.5 Vibrating plate

For a vibrating plate the following "Edit/Systemparameters" dialog box opens:

The dialog box "Vibrating plate" contains the following fields and values:

Section	Field	Value
Base data	Type of building	Residential
	Analyse for:	Unfavourable values
	Distance to building r (m):	10.0
Equipment	Equipment name:	
	Service weight of vibrating plate [t]:	6.300
	Vibrating plate power [kW]:	70.0
	Vibrating plate frequency [1/s]:	50.0
Transmission coefficients	Horizontal transmission coeff. (component) [-]:	2.00
	Vertical transmission coeff. (component) [-]:	1.50

The input corresponds to the input for vibrating pile drivers (see Section 5.2.3.2). However, in addition to power and frequency the service weight of the vibrating plate must be given.

Here, too, the equipment data can be selected and adopted from a list of common commercial appliances using the button of the same name. Equipment selection and editing of the equipment list are described separately in Section 5.2.3.8.

5.2.3.6 Vibratory roller

For a vibratory roller the following "Edit/Systemparameters" dialog box opens:

Base data	
Type of building	Residential
Analyse for:	Unfavourable values
Distance to building r (m):	10.0

Equipment	
Equipment name:	
Service weight of vibratory roller [t]:	6.300
Vibratory roller power [kW]:	70.0
Vibratory roller frequency [1/s]:	50.0

Transmission coefficients		
Horizontal transmission coeff. (component) [-]:	2.00	Info
Vertical transmission coeff. (component) [-]:	1.50	Info

Buttons: OK, Equipment data, Cancel

The input corresponds to the input for vibrating pile drivers (see Section 5.2.3.2). However, in addition to power and frequency the service weight of the vibratory roller must be given.

Here, too, the equipment data can be selected and adopted from a list of common commercial appliances using the button of the same name. Equipment selection and editing of the equipment list are described separately in Section 5.2.3.8.

5.2.3.7 Deep vibrator

For a deep vibrator the following "Edit/Systemparameters" dialog box opens:

The dialog box is titled "Deep vibrator" and contains the following fields and controls:

- Base data:**
 - Type of building: Residential (dropdown)
 - Analyse for: Unfavourable values (dropdown)
 - Distance to building r (m): 10.0 (text input)
- Equipment:**
 - Equipment name: (text input)
 - Deep vibrator power [kW]: 70.0 (text input)
 - Deep vibrator frequency [1/s]: 50.0 (text input)
- Transmission coefficients:**
 - Horizontal transmission coeff. (component) [-]: 2.00 (text input) with Info button
 - Vertical transmission coeff. (component) [-]: 1.50 (text input) with Info button
- Buttons: OK, Equipment data, Cancel

The input corresponds to the input for vibrating pile drivers (see Section 5.2.3.2).

Here, too, the equipment data can be selected and adopted from a list of common commercial appliances using the button of the same name. Equipment selection and editing of the equipment list are described separately in Section 5.2.3.8.

5.2.3.8 Selecting and managing equipment

In all of the system data input dialog boxes for the various appliances described above the required equipment can be selected from a list of common commercial appliances and the data be adopted by the program by pressing the "Equipment data" button. Below you can see an example of a dialog box for vibrating pile drivers (vibratory attachments):

The dialog box is titled "Vibratory attachments" and contains a grid of equipment selection buttons:

ABI HVR 100	ABI HVR 20	ABI HVR 30	ABI HVR 45	ABI HVR 60	ABI HVR 75
ABI MRZV 500 V	Müller MS-1 HFB	Müller MS-10 HFB	Müller MS-17 HFB	Müller MS-2 HFB	Müller MS-3 HFB
Müller MS-4 HFB	Müller MS-4 HFBS	Müller MS-5 HFBV 3	Müller MS-6 HFB	Müller MS-6 HFBS	Müller MS-7 HFB
Müller MS-7 HFBS	Müller MS-8 HFBV 3	Tinkers HVB 16			

Buttons: OK, Cancel, Edit

After clicking an equipment button the corresponding power and frequency are adopted and entered into the main dialog box. If you hover for a moment over an equipment button with the mouse pointer the corresponding data will be briefly displayed.

The data for the existing appliances can be edited or new appliances added by pressing the "Edit" button. The following dialog box for vibrating pile drivers (vibratory attachments) opens:

The screenshot shows a dialog box titled "Vibratory attachments" with a close button (X) in the top right corner. At the top, there are buttons for "Forw.", "Back", "Cancel", "OK", "Save", "Load", and "Sort". Below these buttons is a text box containing "21 Vibratory attachments to edit" and an "Info" button. The main area of the dialog is a table with four columns: "No.", "Name", "Power [kW]", and "Frequency [1/s]". The table contains 21 rows of data, each with a number in the "No." column, a name in the "Name" column, a power value in the "Power [kW]" column, and a frequency value in the "Frequency [1/s]" column.

No.	Name	Power [kW]	Frequency [1/s]
1	ABI HVR 100	180.0	40.0
2	ABI HVR 20	24.0	50.0
3	ABI HVR 30	45.0	50.0
4	ABI HVR 45	65.0	41.0
5	ABI HVR 60	95.0	41.0
6	ABI HVR 75	130.0	41.0
7	ABI MRZV 500 V	130.0	46.0
8	Müller MS-1 HFB	60.0	56.0
9	Müller MS-10 HFB	150.0	39.0
10	Müller MS-17 HFB	158.0	30.0
11	Müller MS-2 HFB	61.0	53.1
12	Müller MS-3 HFB	70.0	50.0
13	Müller MS-4 HFB	100.0	47.5
14	Müller MS-4 HFBS	100.0	47.5
15	Müller MS-5 HFBV 3	95.0	45.0
16	Müller MS-6 HFB	119.0	52.5
17	Müller MS-6 HFBS	119.0	42.5
18	Müller MS-7 HFB	130.0	46.7
19	Müller MS-7 HFBS	100.0	46.7
20	Müller MS-8 HFBV 3	165.0	43.0
21	Tüinkers HVB 16	67.0	35.0

New equipment can be added by clicking the "x Vibratory attachments to edit" button. Enter the required number and then edit the equipment name and the data in the newly added rows. If there are more than 25 rows, navigate between the boxes using "Forw." and "Back".

The appliances can be stored in a file using the "Save" button. If the edited file is saved in the program folder using the name "GGU-Vibration.ggu_vib_db", it is automatically imported when the program is started. Otherwise, a different appliance file can be opened by pressing the "Load" button. The default file suffix for diesel hammers is ".ggu_die_db", for drop hammers ".ggu_fre_db", for vibrating plates ".ggu_pla_db", for vibration rollers ".ggu_wal_db" and for deep vibrators ".ggu_tie_db".


The equipment list can be sorted in ascending or descending order for the name, power or frequency (for vibrating pile drivers) by pressing the "Sort" button. The setting is also stored in the ".ggu_vib_db" file. To delete a piece of equipment, sort the required row to the end of the list and then reduce the number of rows using the "x Vibratory attachments to edit" button.

5.3 System menu

5.3.1 "Analyse" menu item

This menu item starts the analysis of building vibrations. Alternatively, press the [F5] function key or click the *calculator* in the tool bar. First, the input data are checked. A warning message is produced if errors or special features are identified.

Once the analysis is complete information on the data entered and on the analysis results is displayed, as shown in the following box.




If the results shown in the box are to be used in a report, for example, click the **"To clipboard"** button. The data are copied to the WINDOWS clipboard. From there, they can be imported into other WINDOWS programs for further processing, e.g. into a word processor. The *"Edit/Paste"* function of the respective application must generally be used in order to import into any other WINDOWS application.

After confirming with **"OK"** the input and result data are shown in a legend on the screen. In addition, the analysis results are graphically evaluated in a diagram (see Section 5.4.2).

5.4 Output preferences menu

5.4.1 "General legend" menu item

After selecting this menu item a dialog box opens allowing graphics preferences to be selected for displaying a legend containing the input data and the analysis results. The legend is activated by the "**Show legend**" check box. In addition to the input in the dialog box the legend also contains the project identification, if it was entered using the corresponding menu item "**Edit/Project identification**" (see Section 5.2.1). The vibration generating equipment is also filled in automatically. The display of the ground vibration velocity can be activated via the corresponding check box.




You can define and edit the position of the legend using the values "x" and "y". You control the size of the legend using "**Font size**" and "**Max. no. of lines**"; where necessary, several columns are used. The legend background can also be given a colour fill.

The fastest way to modify the position of the legend is to press the **[F11]** function key and then to pull the legend to the new position with the left mouse button pressed.

In the general legend you can, if wished, display information on the program and on the current file. By activating the "**Short**" or "**Long**" option buttons the current file name can be shown in the legend, either with or without the path. Date and/or time can be displayed, too.

5.4.2 "Diagram" menu item

A diagram is shown on the output sheet containing the footing vibration velocity drawn against the distance to the endangered buildings. The format and appearance of this diagram can be edited in this menu item's dialog box, if the "**Show diagram**" check box is activated.



The position and size of the diagram can be defined or edited by means of the variables "**X**" and "**Y**", "**Width**" and "**Height**". The font size can be varied as required. The fastest way to modify the position or size of the diagram is to press [F11] and then to either drag the diagram to the new position or move the sides of the diagram to their new size holding the left mouse button pressed.

The program automatically selects a sensible axes scale for graph visualisation. If the "**User-defined axes**" button is clicked a dialog box opens allowing the "**Use the following axes values**" check box to be activated. The required minimum and maximum distances and velocities can then be given. The x-axis can be displayed on a logarithmic scale by activating the appropriate check box.


Beside the automatic display of the footing vibration velocity in the diagram, the vertical ground vibration velocity and the horizontal and vertical vibration velocity for floors and walls can also be shown. Activate the required check boxes.

The resulting vibration velocity value for the distance to the building entered in "**Edit/System parameters**" is displayed in the diagram if the "**With individual values**" check box is activated in the dialog box. The area behind the graph of the footing vibration velocity is backed using the colour defined by clicking the "**Edit colour**" button if the "**Diagram coloured**" check box is activated.

The distance at which the vibration velocity graphs begin is defined using the input in the "**Min. distance [m]**" box and to which distance on the x-axis using "**Max. distance [m]**". The total length of the x- and y-axes is automatically adapted if the specified distances are altered or are defined by the user using the "**User-defined axes**" button (see above).

5.4.3 "Page size and margins" menu item

The program uses A4 format as default. You can edit the page format in the following dialog box.



Enter the values to be adopted for "**Page height**" and "**Page width**". The program automatically draws thin borders around the page, which are required when using paper rolls on a plotter. "**Page margins**" defines the position of a thickly drawn frame as a distance to these borders.

In order to achieve 1:1 output on an A4 printer the borders must be switched off (see menu item "**Graphics preferences/With borders**", Section 5.5.4) and the page height and page margins be adapted to the printable area of the printer.

5.4.4 "Move objects" menu item

Select this menu item in order to position the legend or the diagram at the desired position on the output sheet. You can also move objects by pressing **[F11]** and then positioning the legend box with the left mouse button pressed. In that case an info-box appears no more.

After going to this menu item the mouse pointer changes to a move pointer (four-headed arrow, points simultaneously *left-right* and *up-down*) when located within the legend or diagram. The element can then be moved to a different position on the sheet. This menu item must be reactivated after each movement to carry out further alterations.


The size of the diagram can also be altered. To change the size move the pointer to the upper or right diagram boundary. If the pointer is located above the edge it changes to a simple double arrow, which points either *left-right* or *up-down*. Move the corresponding boundary while holding the left mouse button.

5.5 Graphics preferences menu

5.5.1 "Refresh and zoom" menu item

The program works on the principle of *What you see is what you get*. This means that the screen presentation represents, overall, what you will see on your printer. In the last consequence, this would mean that the screen presentation would have to be refreshed after every alteration you make. For reasons of efficiency and as this can take several seconds for complex screen contents, the screen is not refreshed after every alteration.

If, e.g., after using the zoom function (see below), only part of the image is visible, you can achieve a complete view using this menu item.



A zoom factor between 0.4 and 8.0 can be entered in the input box. By then clicking on "Use" to exit the box the current factor is accepted. By clicking on the "0.4", "0.6", etc. buttons, the selected factor is used directly and the dialog box closed.

It is much simpler, however, to get a complete overview using [Esc]. Pressing [Esc] allows a complete screen presentation using the zoom factor specified in this menu item. The [F2] key allows screen refreshing without altering the coordinates and zoom factor.

5.5.2 "Zoom info" menu item

By clicking two diametrically opposed points you can enlarge a section of the screen in order to view details better. An information box provides information on activating the zoom function and on available options.

5.5.3 "Legend font selection" menu item


With this menu item you can switch to a different true-type font. All available true-type fonts are displayed in the dialog box.

5.5.4 "With borders" menu item

The program automatically draws thin cutting borders around the page, which are required when using a plotter on paper rolls. You can switch off the lines by deactivating this menu item.

5.5.5 "Pen colour and width" menu item

In order to enhance the clarity of the graphics you can edit the pen settings for various graphic elements.



The pen width and the dashing can be specified for the elements listed in the dialog box. After clicking the appropriate button the pen colours can be adapted.

5.5.6 "Mini-CAD toolbar" menu item

Using this menu item you can add free text, lines, circles, polygons and images (e.g. files in formats BMP, JPG, PSP, TIF, etc.) to the main program graphics. A pop-up menu opens, the icons and functions used are described in more detail in the **Mini-CAD** manual provided.

Objects created with the "**Mini-CAD**" tool are based on the page format (in mm). This makes you independent of the coordinate system and keeps you in the same position on the page. You should select the "**Mini-CAD toolbar**" if you wish to place general information on the drawing (company logo, report numbers, plan numbers, stamp etc.). Once you have saved the header information to disk (see **Mini-CAD** user manual), you can load it into completely different systems (with different system coordinates). The saved header information will appear in exactly the same position on the page, which greatly simplifies the creation of general page information.

5.5.7 "Toolbar preferences" menu item

After starting the program a horizontal toolbar appears below the program menu bar. If you would rather work with a popup window with several columns, you can specify your preferences using this menu item. The smarticons can also be switched off.

At the bottom of the program window you find a status bar with further information. You can also activate or switch off the status bar here. The preferences will be saved in the "**GGU-VIBRATION.alg**" file (see menu item "**Graphics preferences/Save graphics preferences**") and will be active at the next time the program is started.

By clicking on the tools (smarticons) for the menu items you can directly reach most of the program functions. The meaning of the smarticons appears as a text box if you hover with the mouse pointer over the tools. Some of the tool functions cannot be activated from the normal menu items.



"Zoom out"

If you have previously *zoomed in*, this tool returns to a full screen display.



"Zoom (-)"/"Zoom (+)"

With the zoom functions you can zoom in or out of parts of the image, by clicking the left mouse button.



"Copy/print area"

Use this tool to copy only parts of the graphics in order to paste them, e.g. to a report. You will see information on this function and can then mark an area, which is copied to the clipboard or can be saved in a file. Alternatively you can send the marked area directly to your printer (see "**Tips and tricks**", Section 6.3).



"Colour on/off"

Use this on/off switch to quickly colour the area behind the footing vibration velocity graph.

5.5.8 "Load graphics preferences" menu item

You can reload a graphics preferences file into the program, which was saved using the "**Graphics preferences/Save graphics preferences**" menu item. Only the corresponding data will be refreshed.

5.5.9 "Save graphics preferences" menu item

Some of the preferences you made with the menu items of the "**Graphics preferences**" menu can be saved to a file. If you select "**GGU-VIBRATION.alg**" as file name, and save the file on the same level as the program, the data will be automatically loaded the next time the program is started and need not be entered again.

If you do not go to "**File/New**" upon starting the program, but open a previously saved file instead, the preferences used at the time of saving are shown. If subsequent changes in the general preferences are to be used for existing files, these preferences must be imported using the menu item "**Graphics preferences/Load graphics preferences**".

5.6 Info menu

5.6.1 "Copyright" menu item

You will see a copyright message and information on the program version number.

The "System" button shows information on your computer configuration and the folders used by GGU-VIBRATION.

5.6.2 "Help" menu item

The GGU-VIBRATION manual is opened as a PDF document. The help function can also be accessed using the [F1] function key.

5.6.3 "GGU on the web" menu item

Using this menu item you can access the GGU Software website: www.ggu-software.com. Keep in touch with new program versions and the regular *download* offers.

If you would like to be automatically notified about program innovations, please register for the Newsletter in our Knowledge Base. Go to the following website: <http://kbase.civilserve.com>.

5.6.4 "GGU support" menu item

This menu item takes to the GGU-Software [Support area](http://www.ggu-software.com/support) at www.ggu-software.com.

5.6.5 "What's new?" menu item

You will see information on program improvements in comparison to older versions.

5.6.6 "Language preferences" menu item

This menu item allows you to switch the menus and the graphics from German to English and vice versa. To work in German, deactivate the two check boxes "**Dialoge + Menüs übersetzen (translate dialogues, menus)**" und "**Graphiktexte übersetzen (translate graphics)**".

Alternatively, you can work bilingually, e.g. with German dialog boxes but with graphic output in English. The program always starts with the language setting applicable when it was last ended.


6 Tips and tricks

6.1 Keyboard and mouse

You can scroll the screen with the keyboard using the cursor keys and the [**Page up**] and [**Page down**] keys. By clicking and pulling with the mouse, with [**Ctrl**] pressed, you activate the zoom function, i.e. the selected section will fill the screen. Furthermore you can use the mouse wheel to zoom in/out or scrolling the screen presentation. The following mouse wheel functions are available:

- Mouse wheel up = move screen image up
- Mouse wheel down = move screen image down
- [**Ctrl**] + mouse wheel up = enlarge screen image (zoom in)
- [**Ctrl**] + mouse wheel down = shrink screen image (zoom out)
- [**Shift**] + mouse wheel up = move screen image right
- [**Shift**] + mouse wheel down = move screen image left

If you click the right mouse button anywhere on the screen a context menu containing the principal menu items opens.




By double-clicking the left mouse button on legends, diagrams or **Mini-CAD** objects, you will immediately move to the editor for the selected object and can then edit it.

6.2 Function keys

Some of the function keys are assigned program functions. The allocations are noted after the corresponding menu items. The individual function key allocations are:

- [**Esc**] refreshes the screen contents and sets the screen back to the given format (A4). This is useful if, for example, you have used the zoom function to display parts of the screen and would like to quickly return to a complete overview.
- [**F1**] opens the manual file.
- [**F2**] refreshes the screen without altering the current magnification.
- [**F3**] opens the menu item "**Edit/System parameters**".
- [**F5**] opens the menu item "**System/Analyse**".
- [**F11**] activates the menu item "**Output preferences/Move objects**".


6.3 "Copy/print area" icon

A dialog box opens when the "Copy/print area" icon  in the menu toolbar is clicked, describing the options available for this function. For example, using this icon it is possible to either copy areas of the screen graphics and paste them into the report, or send them directly to a printer.

In the dialog box, first select where the copied area should be transferred to: "Clipboard", "File" or "Printer". The cursor is displayed as a cross after leaving the dialog box and, keeping the left mouse button pressed, the required area may be enclosed. If the marked area does not suit your requirements, abort the subsequent boxes and restart the function by clicking the icon again.

If "Clipboard" was selected, move to the MS Word document (for example) after marking the area and paste the copied graphics using "Edit/Paste".

If "File" was selected, the following dialog box opens once the area has been defined:



The default location of the file is the folder from which the program is started and, if several files are created, the file is given the file name "Image0.emf" with sequential numbering. If the "Rename" button in the dialog box is clicked, a file selector box opens and the copied area can be saved under a different name in a user-defined folder. Saving can be aborted by pressing the "Delete" button.

If the "Printer" button was pressed in the first dialog box, a dialog box for defining the printer settings opens after marking the area. Following this, a dialog box for defining the image output settings opens. After confirming the settings the defined area is output to the selected printer.

7 Index

- A**
- Analysis results,
 - copy to clipboard..... 19
 - display in diagram..... 21
 - display in legend 20
 - Axes scale, define for diagram 21
- B**
- Building type, select for analysis..... 11
- C**
- Clipboard..... 8
 - CodeMeter stick..... 4
 - Colour, switch on/off in diagram..... 25
 - Colour/pens, define for vibration velocity 24
 - Company logo, add via Mini-CAD 24
 - Context menu, open..... 27
 - Copy/print area..... 8, 25, 28
 - Cutting borders, switch on/off 23
- D**
- Deep vibrator, enter system parameters..... 17
 - Description of record,
 - display 20
 - enter 10
 - Diagram,
 - activate display..... 21
 - change size using mouse 22
 - define axes scale..... 21
 - move with mouse 22
 - Distance to building,
 - edit display in diagram 21
 - specify for analysis..... 12
 - Driving ram with diesel hammer,
 - enter system parameters 13
 - Driving ram with drop hammer,
 - enter system parameters 14
 - DXF file,
 - export 7
 - import via Mini-CAD..... 4
- E**
- EMF format 8
 - Equipment data,
 - adopt from data base 17
 - enter for driving rams..... 14
 - enter for vibration equipment..... 12
 - save/load 18
 - Equipment,
 - choose 10
 - display in legend 10
 - enter performance data..... 17
 - Example analyses Bulletin 61..... 4
 - Exceeding probability, select for analysis 12
- F**
- File,
 - display name in legend..... 20
 - load/save 6
 - Floor vibration velocity,
 - activate display in diagram..... 21
 - Font, select..... 23
 - Footing vibration velocity,
 - activate display in diagram..... 21
 - Function keys 27
- G**
- General page informations,
 - add via Mini-CAD..... 24
 - GGU-CAD file, export 7
 - GGUMiniCAD file, export..... 8
 - Graphics, add via Mini-CAD..... 24
 - Ground vibration acceleration,
 - determination according Bulletin 61 12
 - Ground vibration velocity,
 - activate display in diagram..... 21
 - activate display in legend..... 20
- I**
- Installation 4
- K**
- Knowledge Base, access..... 26
- L**
- Language preferences 4, 26
 - Legend, move with mouse 22
 - Licence protection 4
- M**
- Manual, open as PDF file 26
 - Metafile, export 8
 - Mini-CAD,
 - export file 8
 - use 24
 - Mouse click functions..... 27
 - Mouse wheel functions..... 27
- O**
- Objects, move with mouse..... 22
- P**
- Page,
 - copy/print section..... 25, 28
 - define format 22
 - define margins..... 22

Pen settings.....	24
Print,	
graphics.....	7
section.....	8, 25, 28
several files.....	9
Printer preferences.....	6, 7
Program,	
display name in legend.....	20
load/save preferences.....	25
show improvements.....	26
show information.....	26
Project data, add via Mini-CAD.....	24
Project description,	
display.....	20
enter.....	10

R

Resulting vibration velocity,	
enter in diagram.....	21

S

Scroll the screen.....	27
Smarticons, for menu items.....	25
Soil type, select for driving rams.....	13
Status bar main program, activate.....	24
Structural vibrations, analyse.....	19
System parameters,	
display in legend.....	20
enter.....	11
System, show information.....	26

T

Toolbar, edit for menu items.....	24
Translation, activate.....	26
Transmission coefficients,	
specify for analysis.....	12
True-type font.....	23

V

Version number,	
display in a message box.....	26
display in legend.....	20
Vibrating pile driver,	
enter system parameters.....	11
Vibrating plate, enter system parameters.....	15
Vibration velocities,	
activate display in diagram.....	21
define colours in diagram.....	24
enter resulting values in diagram.....	21
Vibratory roller, enter system parameters.....	16

W

What you see is what you get.....	23
Working frequency, select for analysis.....	12

Z

Zoom factor, define for full-screen display.....	23
Zoom function, activate.....	23, 25, 27