


Analysis of a pile in a slope to code ZTV-Lsw 88

GGU-SLOPE-PILE

VERSION 2



Last revision: September 2008
Copyright: GGU Zentrale Verwaltung mbH, Braunschweig
Technical implementation and sales: Civilserve GmbH, Steinfeld

Contents:

- 1 Preface 4**
- 2 Licence protection and installation 4**
- 3 Language selection..... 5**
- 4 Starting the program 5**
- 5 Description of menu items..... 6**
 - 5.1 File menu..... 6
 - 5.1.1 "New" menu item..... 6
 - 5.1.2 "Load" menu item 6
 - 5.1.3 "Save" menu item 6
 - 5.1.4 "Save as" menu item 6
 - 5.1.5 "Printer preferences" menu item 6
 - 5.1.6 "Print and export" menu item 7
 - 5.1.7 "Batch print" menu item 9
 - 5.1.8 "Exit" menu item..... 9
 - 5.1.9 "1, 2, 3, 4" menu items..... 9
 - 5.2 Edit menu 10
 - 5.2.1 "Project identification" menu item..... 10
 - 5.2.2 "System parameters" 10
 - 5.3 System menu 11
 - 5.3.1 "Analyse" menu item 11
 - 5.4 Output preferences menu 12
 - 5.4.1 "File name legend" menu item..... 12
 - 5.4.2 "System visualisation" menu item 13
 - 5.4.3 "Input data legend" menu item 13
 - 5.4.4 "Results legend" menu item..... 14
 - 5.4.5 "Page size and margins" menu item..... 14
 - 5.4.6 "With borders" menu item 14
 - 5.4.7 "Move objects" menu item..... 15
 - 5.5 Graphics preferences menu 15
 - 5.5.1 "Refresh and zoom" menu item 15
 - 5.5.2 "Zoom info" menu item 15
 - 5.5.3 "Legend font selection" menu item..... 15
 - 5.5.4 "Pens + colours" menu item..... 16
 - 5.5.5 "Mini-CAD" menu item..... 16
 - 5.5.6 "Toolbar preferences" menu item 16
 - 5.5.7 "Load graphics preferences" menu item 17
 - 5.5.8 "Save graphics preferences" menu item..... 17

5.6	Info menu	18
5.6.1	"Copyright" menu item	18
5.6.2	"Help" menu item	18
5.6.3	"GGU on the web" menu item	18
5.6.4	"GGU support" menu item.....	18
5.6.5	"What's new" menu item.....	18
5.6.6	"Language preferences" menu item	18
6	Tips.....	19
7	Index.....	20

1 Preface

The **GGU-SLOPE-PILE** program system is based on the supplements to the Additional Technical Regulations and Guidelines for the Installation of Noise Abatement Walls on Roads (*Zusätzliche Technische Vorschriften und Richtlinien für die Ausführung von Lärmschutzwänden an Straßen* (ZTV-Lsw 88)) published by the Forschungsgesellschaft für Straßen- und Verkehrswesen (FGSV): **Design and Analysis Principles for Bored Pile Foundations and Steel Posts for Noise Abatement Walls on Roads** (*Entwurfs- und Berechnungsgrundlagen für Bohrpfehlgründungen und Stahlpfosten von Lärmschutzwänden an Straßen*) (1997 edition).

The theoretical principles are described in detail in ZTV-Lsw 88, Supplements 97. The program works exactly to these specifications; we therefore refer you to them for further details.

Data input is in accordance with conventional WINDOWS operations and can therefore be learned almost entirely without the use of a manual. Graphic output supports the true-type fonts supplied with WINDOWS, so that excellent layout is guaranteed. Colour output and any graphics (e.g. files in formats BMP, JPG, PSP, TIF, etc.) are supported. DXF files can also be imported by means of the integrated Mini-CAD module (see the "**Mini-CAD**" manual).

The program has been thoroughly tested. No faults have been found. Nevertheless, liability for completeness and correctness of the program and the manual, and for any damage resulting from incompleteness or incorrectness, cannot be accepted.

2 Licence protection and installation

In order to guarantee a high degree of quality, a hardware-based copy protection system is used for the **GGU-SLOPE-PILE** program.

The GGU software protected by the *CodeMeter* copy protection system is only available in conjunction with the *CodeMeter stick* copy protection component (hardware for connection to the PC, "*CM stick*"). Because of the way the system is configured, the protected software can only be operated with the corresponding CM stick. This creates a fixed link between the software licence and the CM stick copy protection hardware; the licence as such is thus represented by the CM stick. The correct Runtime Kit for the CodeMeter stick must be installed on your PC.

Upon start-up and during running, the **GGU-SLOPE-PILE** program checks that a CM stick is connected. If it has been removed, the program can no longer be executed.

For installation of GGU software and the CodeMeter software please refer to the information in the *Installation notes for GGU Software International*, which are supplied with the program.

3 Language selection

GGU-SLOPE-PILE is a bilingual program. The program always starts with the language setting applicable when it was last ended.

The language preferences can be changed at any time in the "**Info**" menu, using the menu item "**Spracheinstellung**" (for German) or "**Language preferences**" (for English).

4 Starting the program

After starting the program, you will see two menus at the top of the window:

- File
- Info

After clicking on the "**File**" menu, a previously calculated system can be loaded by means of the "**Load**" menu item, or a new one created using "**New**".

After clicking "**New**" a project description can be entered in a dialogue box, which is later displayed in the "**File name legend**". After closing the box (whether with "**OK**" or "**Cancel**") the start-up screen appears. Six menus are visible in the menu bar:

- File
- Edit
- System
- Output preferences
- Graphics preferences
- Info

After clicking one of these menus, the so-called menu items roll down, allowing access to all program functions.

The program works on the principle of *What you see is what you get*. This means that the screen presentation represents, overall, what you will see on your printer. In the last consequence, this would mean that the screen presentation would have to be refreshed after every alteration you make. For reasons of efficiency and as this can take several seconds for complex screen contents, the **GGU-SLOPE-PILE** screen is not refreshed after every alteration.

If you would like to refresh the screen contents, press either [F2] or [Esc]. The [Esc] key additionally sets the screen visualisation back to your current zoom, which has the default value 1.0, corresponding to an A4 format sheet.

5 Description of menu items

5.1 File menu

5.1.1 "New" menu item

A new system can be entered. The dialogue box for entering the project identification therefore opens; this project identification later appears in the *General legend* (see menu item "**Edit/Project identification**", Section 5.2.1).

5.1.2 "Load" menu item

You can load a file with system data, which was created and saved at a previous session, and then edit the system.

5.1.3 "Save" menu item

You can save data entered or edited during program use to a file, in order to have them available at a later date, or to archive them. The data is saved without prompting with the name of the current file.

5.1.4 "Save as" menu item

You can save data entered during program use to an existing file or to a new file, i.e. using a new file name. For reasons of clarity, it makes sense to use ".pfa_boe" as file suffix, as this is the suffix used in the file requester box for the menu item "**File/Load**". If you choose not to enter an extension when saving, ".pfa_boe" will be used automatically.


5.1.5 "Printer preferences" menu item

You can edit printer preferences (e.g. swap between portrait and landscape) or change the printer in accordance with WINDOWS conventions.

5.1.6 "Print and export" menu item

You can select your output format in a dialogue box. You have the following possibilities:


- **"Printer"**
allows graphic output of the current screen contents. to the WINDOWS standard printer or to any other printer selected using the menu item **"File/Printer preferences"**. But you may also select a different printer in the following dialogue box by pressing the **"Printer prefs./change printer"** button.



In the upper part of the dialogue box, the maximum dimensions which the printer can accept are given. Below this, the dimensions of the image to be printed are given. If the image is larger than the output format of the printer, the image will be printed to several pages (in the above example, 4). In order to facilitate better re-connection of the images, the possibility of entering an overlap for each page, in x and y direction, is given. Alternatively, you also have the possibility of selecting a smaller zoom factor, ensuring output to one page ("**Fit to page**" button). Following this, you can enlarge to the original format on a copying machine, to ensure true scaling. Furthermore, you may enter the number of copies to be printed.

- **"DXF file"**
allows output of the graphics to a XF file. DXF is a common file format for transferring graphics between a variety of applications.
- **"GGUCAD file"**
allows output of the graphics to a file, in order to enable further processing with the GGUCAD program. Compared to output as a DXF file this has the advantage that no loss of colour quality occurs during export.

- **"Clipboard"**
The graphics are copied to the WINDOWS clipboard. From there, they can be imported into other WINDOWS programs for further processing, e.g. into a word processor. In order to import into any other WINDOWS program you must generally use the "*Edit/Paste*" function of the respective application.
- **"Metafile"**
allows output of the graphics to a file in order to be further processed with third party software. Output is in the standardised EMF format (Enhanced Metafile format). Use of the Metafile format guarantees the best possible quality when transferring graphics.


If you select the **"Copy/print area"** tool  from the toolbar, you can copy parts of the graphics to the clipboard or save them to an EMF file. Alternatively you can send the marked area directly to your printer.

Using the **"Mini-CAD"** program module you can also import EMF files generated using other GGU applications into your graphics.

- **"MiniCAD"**
allows export of the graphics to a file in order to enable importing to different GGU applications with the Mini-CAD module.
- **"GGUMiniCAD"**
allows export of the graphics to a file in order to enable processing in the GGUMiniCAD program.
- **"Cancel"**
Printing is cancelled.

5.1.7 "Batch print" menu item

If you would like to print several appendices at once, select this menu item. You will see the following dialogue box:



Create a list of files for printing using "**Add**" and selecting the desired files. The number of files is displayed in the dialogue box header. Using "**Delete**" you can mark and delete selected individual files from the list. After selecting the "**Delete all**" button, you can compile a new list. Selection of the desired printer and printer preferences is achieved by pressing the "**Printer**" button.

You then start printing by using the "**Print**" button. In the dialogue box which then appears you can select further preferences for printer output such as, e.g., the number of copies. These preferences will be applied to all files in the list.

5.1.8 "Exit" menu item

After a confirmation prompt, you can quit the program.

5.1.9 "1, 2, 3, 4" menu items

The "**1, 2, 3, 4**" menu items show the last four files worked on. By selecting one of these menu items the listed file will be loaded. If you have saved files in any other folder than the program folder, you can save yourself the occasionally onerous *rummaging* through various sub-folders.

5.2 Edit menu

5.2.1 "Project identification" menu item

A description typifying the system can be entered; it will then be included in the *File name legend* (see Section 5.4.1).

5.2.2 "System parameters"

The relevant system data are entered using this menu item. The following dialogue box opens, for example:

Parameter	Value
Slope inclination [°]	33.70
Friction angle [°]	35.00
Cohesion [kN/m ²]	0.00
Faktor Kohäsion (i.a. = 0,5)	0.50
Unit weight [kN/m ³]	19.00
Wall friction angle/friction angle [-]	0.500
Width of pile [m]	0.70
Safety factor [-]	1.40
Horizontal force [kN]	70.50
Moment [kN*m]	60.36


All system parameters entered using this menu item are displayed in a legend on the output sheet (see menu item "**Output preferences/Input data legend**", Section 5.4.3).

5.3 System menu

5.3.1 "Analyse" menu item

This menu item starts the analysis to ZTV-Lsw 88. Alternatively, press the [F5] function key or click the *calculator* in the tool bar. First, the input data are checked. A warning message is produced if errors are identified.

Once the analysis is complete information on the data entered and on the analysis results is displayed, as shown in the following box.




After confirming with "OK" the input and result data are shown on the screen in two legends. In addition, the analysis results are displayed graphically in a system sketch.

5.4 Output preferences menu

5.4.1 "File name legend" menu item

If the "**Show legend**" check box is activated in this menu item's dialogue box, a legend containing the file name is displayed. Any project identification entered (see Section 5.2.1), also be shown in the legend. The shape and appearance of the legend can be altered.




You can define and edit the position of the legend using the values "**x**" and "**y**". You control the size of the legend using "**Font size**". The fastest way to modify the position of the legend is to press the [**F11**] function key and then to pull the legend to the new position with the left mouse button pressed.

The legend can be displayed with a frame. By activating the "**Short**" or "**Long**" option buttons the current file name can be shown in the legend, either with or without the path.

5.4.2 "System visualisation" menu item

The system is graphically represented if you have clicked the "Show system" check box. You can alter the shape and appearance of the system visualisation..




You can define and edit the position of the legend using the values "x" and "y". The fastest way to modify the position of the legend is to press the [F11] function key and then to pull the legend to the new position with the left mouse button pressed.

The labelling font size can be altered to suit user requirements. If the "System coloured" check box is activated the soil and the pile are shown in the system visualisation in the colours defined in menu item "Graphics preferences/Pens + colours" (see Section 5.5.4).

5.4.3 "Input data legend" menu item

If you click the "Show legend" check box, a legend with input data will be displayed. You can alter the position and appearance of the legend.



A text can be specified as legend header. You can define and edit the position of the legend using the values "x" and "y". You control the size of the legend using "Font size" and "Max. no. of lines"; where necessary, several columns are used. The fastest way to modify the position of the legend is to press the [F11] function key and then to pull the legend to the new position with the left mouse button pressed.


5.4.4 "Results legend" menu item

If you have analysed your system the detailed analysis results can be shown in a legend by activating the **"Show legend"** check box. You can alter the position and appearance analogous to the input data legend.

A text can be specified as legend header. You can define and edit the position of the legend using the values **"x"** and **"y"**. You control the size of the legend using **"Font size"** and **"Max. no. of lines"**; where necessary, several columns are used. The fastest way to modify the position of the legend is to press the [F11] function key and then to pull the legend to the new position with the left mouse button pressed.

5.4.5 "Page size and margins" menu item

The program uses A4 format as default. You can edit the page format in the following dialogue box.



- **"Page in general"** defines the size of the output sheet. Enter the values to be adopted for **"Page height"** and **"Page width"**.

The program automatically draws thin cutting borders around the page, which are required when using a plotter on paper rolls. The borders can be switched off using the menu item **"Output preferences/With borders"** (see Section 5.4.6).

- **"Page margin"** defines the position of a frame as a distance to the margins. This frame encloses the subsequent diagram.

In order to achieve 1:1 output on an A4 printer the borders must be switched off and the page height and page margins be adapted to the printable area of the printer.

5.4.6 "With borders" menu item

The program automatically draws thin cutting borders around the page, which are required when using a plotter on paper rolls. You can switch off the lines by deactivating this menu item.

5.4.7 "Move objects" menu item


Select this menu item in order to position the legend or other graphical elements at the desired position on the output sheet. You can also move objects by pressing [F11] and then positioning the legend box with the left mouse button pressed. In that case an info-box appears no more.

5.5 Graphics preferences menu

5.5.1 "Refresh and zoom" menu item

The program works on the principle of *What you see is what you get*. This means that the screen presentation represents, overall, what you will see on your printer. In the last consequence, this would mean that the screen presentation would have to be refreshed after every alteration you make. For reasons of efficiency and as this can take several seconds for complex screen contents, the screen is not refreshed after every alteration.

If, e.g., after using the zoom function (see below), only part of the image is visible, you can achieve a complete view using this menu item.



A zoom factor between 0.4 and 8.0 can be entered in the input box. By then clicking on "Use" to exit the box the current factor is accepted. By clicking on the "0.4", "0.6", etc. buttons, the selected factor is used directly and the dialogue box closed.

It is much simpler, however, to get a complete overview using [Esc]. Pressing [Esc] allows a complete screen presentation using the zoom factor specified in this menu item. The [F2] key allows screen refreshing without altering the coordinates and zoom factor.

5.5.2 "Zoom info" menu item


By clicking two diametrically opposed points you can enlarge a section of the screen in order to view details better. An information box provides information on activating the zoom function and on available options.

5.5.3 "Legend font selection" menu item

With this menu item you can switch to a different true-type font. All available true-type fonts are displayed in the dialogue box.

5.5.4 "Pens + colours" menu item

The soil and pile colours for the coloured visualisation of the system can be edited in this menu item's dialogue box.



The pen widths for the elements shown in the dialogue box can be edited and/or; by clicking on the button with the element designation, the pen or fill colours can also be edited.

5.5.5 "Mini-CAD" menu item

Using this menu item you can add free text to the graphics and add lines, circles, polygons and images (e.g. files in formats BMP, JPG, PSP, TIF, etc.). A pop-up menu opens, the icons and functions used are described in more detail in the **Mini-CAD** manual provided.

Objects created with the "**Mini-CAD**" tool are based on the page format (in mm). This makes you independent of the coordinate system and keeps you in the same position on the page. You should select the "**Mini-CAD toolbar**" if you wish to place general information on the drawing (company logo, report numbers., plan numbers, stamp etc.). Once you have saved the header information to disk (see **Mini-CAD** user manual), you can load it into completely different systems (with different system coordinates). The saved header information will appear in exactly the same position on the page, which greatly simplifies the creation of general page information.

5.5.6 "Toolbar preferences" menu item

After starting the program a horizontal toolbar appears below the program menu bar. If you would rather work with a popup window with several columns, you can specify your preferences using this menu item. The smarticons can also be switched off.

At the bottom of the program window you find a status bar with further information. You can also activate or switch off the status bar here. The preferences will be saved in the "**GGU-SLOPE-PILE.alg**" file (see menu item "**Graphics preferences/Save graphics preferences**") and will be active at the next time the program is started.

By clicking on the tools (smarticons) for the menu items you can directly reach most of the program functions. The meaning of the smarticons appears as a text box if you hover with the mouse pointer over the tools. Some of the tool functions cannot be activated from the normal menu items.



"Zoom out"

If you have previously *zoomed in*, this tool returns to a full screen display.



"Zoom (-)"/"Zoom (+)"

With the zoom functions you can zoom in or out of parts of the image, by clicking the left mouse button.



"Copy/print area"

Use this tool to copy only parts of the graphics in order to paste them, e.g. to a report. You will see information on this function and can then mark an area, which is copied to the clipboard or can be saved in a file. Alternatively you can send the marked area directly to your printer.



"Colour on/off"

If you prefer to do without colour in the system visualisation, e.g. to create a black and white printout, use this on/off switch.

5.5.7 "Load graphics preferences" menu item

You can reload a graphics preferences file into the program, which was saved using the "**Graphics preferences/Save graphics preferences**" menu item. Only the corresponding data will be refreshed.

5.5.8 "Save graphics preferences" menu item

Some of the preferences you made with the menu items of the "**Graphics preferences**" menu can be saved to a file. If you select "**GGU-SLOPE-PILE.alg**" as file name, and save the file on the same level as the program, the data will be automatically loaded the next time the program is started and need not be entered again.

5.6 Info menu

5.6.1 "Copyright" menu item

You will see a copyright message and information on the program version number.

The "**System**" button shows information on your computer configuration and the folders used by **GGU-SLOPE-PILE**.

5.6.2 "Help" menu item

The **GGU-SLOPE-PILE** online-help is opened using an installed browser (e.g. MS Internet Explorer). The help function can also be accessed using the [**F1**] function key.

5.6.3 "GGU on the web" menu item

Using this menu item you can access the GGU Software website: www.ggu-software.com. Keep in touch with new program versions and the regular *download* offers.

If you would like to be automatically notified about program innovations, please register for the Newsletter in our Knowledge Base. Go to the following website: <http://kbase.civilserve.com>.

5.6.4 "GGU support" menu item

This menu item takes to the GGU-Software [Support area](http://www.ggu-software.com/support) at www.ggu-software.com.

5.6.5 "What's new" menu item

You will see information on program improvements in comparison to older versions.

5.6.6 "Language preferences" menu item

This menu item allows you to switch the menus and the graphics from German to English and vice versa. To work in German, deactivate the two switches "**Dialoge + Menüs übersetzen (translate dialogues, menus)**" und "**Graphiktexte übersetzen (translate graphics)**".


Alternatively, you can work bilingually, e.g. with German dialogue boxes but with graphic output in English. The program always starts with the language setting applicable when it was last ended.

6 Tips

You can scroll the screen with the keyboard using the cursor keys and the [**Page up**] and [**Page down**] keys. By clicking and pulling with the mouse, with [**Ctrl**] pressed, you activate the zoom function, i.e. the selected section will fill the screen. Furthermore you can use the mouse wheel to zoom in/out or scrolling the screen presentation. The following mouse wheel functions are available:

- Mouse wheel up = move screen image up
- Mouse wheel down = move screen image down
- [**Ctrl**] + mouse wheel up = enlarge screen image (zoom in)
- [**Ctrl**] + mouse wheel down = shrink screen image (zoom out)
- [**Shift**] + mouse wheel up = move screen image right
- [**Shift**] + mouse wheel down = move screen image left

If you click the right mouse button anywhere on the screen a context menu containing the principal menu items opens.



By double-clicking the left mouse button on legends, diagrams or Mini-CAD objects, you will immediately move to the editor for the selected object and can then edit it.

Some of the function keys are assigned program functions. The allocations are noted after the corresponding menu items. The individual function key allocations are:

- [**Esc**] refreshes the screen contents and sets the screen back to the given format (A4). This is useful if, for example, you have used the zoom function to display parts of the screen and would like to quickly return to a complete overview.
- [**F1**] opens the online-help.
- [**F2**] refreshes the screen without altering the current magnification.
- [**F3**] opens the menu item "**Edit/System parameters**".
- [**F5**] opens the menu item "**System/Analyse**".
- [**F11**] activates the menu item "**Output preferences/Move objects**".

7 Index

- A**
- Analysis results, display in legend 14
- C**
- Clipboard 8
CodeMeter stick 4
Colour, define for soil/pile in system
 visualisation 16
Company logo, add via Mini-CAD 16
Context menu 19
Copy/print area 8, 17
Cutting borders, switch on/off 14
- D**
- Description of record, enter 10
DXF file, export 7
DXF file, import 4
- E**
- EMF format 8
- F**
- File, display name in legend 12
File, load/save 6
Font, select 15
Function keys 19
- G**
- General page informations, add via
 Mini-CAD 16
GGUCAD file, export 7
GGUMiniCAD file, export 8
Graphics, add via Mini-CAD 16
- I**
- Input data legend, activation/settings 13
Installation 4
- K**
- Knowledge Base 18
- L**
- Language preferences 5, 18
Legend, move with mouse 15
Licence protection 4
- M**
- Metafile, export 8
Mini-CAD file, export 8
Mini-CAD, use 16
Mouse wheel functions 19
- P**
- Page format, define 14
Page margins, define 14
Pen preferences 16
Pile, activate coloured visualisation in
 system sketch 13, 17
Pile, define colour for system visualisation 16
Preferences, program 17
Print, graphics 7
Print, section 8
Print, several files 9
Printer preferences 6, 7
Program, improvements 18
Program, information 18
Program, preferences 17
Project data, add via Mini-CAD 16
Project description, display 10
Project description, show 12
- R**
- Results legend, activation/settings 14
- S**
- Scroll the screen 19
Smarticons, for menu items 16
Soil, activate coloured visualisation in
 system sketch 13, 17
Soil, define colour for system visualisation 16
Status bar main program, activate 16
System data, display in legend 13
System, analyse 11
System, display activation/settings 13
System, information 18
System, switch coloured visualisation on/off ... 17
- T**
- Toolbar, for menu items 16
Translation 18
True-type font 15

W

What you see is what you get 15

Z

Zoom factor, define for full-screen display 15
Zoom function 15, 17, 19